

## Stop delay

## Function of the component:

With the function component stop delay, turning off consumers can be performed delayed. Results of a calculation (e.g. hysteresis component) can also be switched off delayed.



- Go to "Controls" in "Device configuration". Create a new control function with the green plus
- Go to "Functions" and create a new component with "Stop delay".
- Enter a name at "Name" e.g. air conditioning.
- Select your function component at "Sensor/Counter" e.g.: hysteresis of the stop delay.
- At "Interface" enter e.g.: DO\_Relais.
- At "Delay" enter the desired start delay in seconds e.g. "10"
- Confirm with "Ok". Go to the device configuration an press "Save".