

ON/OFF timer

Function of the component:

The function component ON/OFF timer is a component, that provides the ON- and OFF time of the interface.



- Go to „Controls“ in „Device configuration“. Create a new control function with the green plus
- Go to „Functions“ and create a „ON/OFF timer“ component.
- At „Name“ enter e.g. blinking light.
- At „ON time“ select the turn on time in seconds e.g.: „2“
- At „OFF time“ select the turn off time in seconds e.g.: „2“
- At „Interface“ enter e.g.: DO_Virtual.
- Confirm with „OK“. Then go to the device configuration and press „Save“.