

Set/Reset

Function of the component:

The function component Set/Reset is a function, that can have two different states. Set – ON, or Reset - OFF. The Flip-flop is a basic component in sequential circuits and therefore an essential element in digital technic.



- Go to „Controls“ in „Device configuration“. Create a new control function with the green plus
- Go to „Functions“ and create a „Set/Reset“ component.
- At „Name“ enter e.g.: Set/Reset.
- At „Set parameters“ select your function component e.g.: hysteresis for turning on.
- Select your function component at „Reset parameters“ e.g.: Reset for turning off.
- At „Interface“ enter e.g.: DO_Virtual an.
- Confirm with „OK“. Then go to the device configuration and press „Save“