

Start delay

Function of the component:

With the function component start delay, an order can be made of which consumers turn on first. Results of a calculation (e.g. hysteresis component) can also be triggered delayed.



- Go to „Controls“ in „Device configuration“. Create a new control function with the green plus
- Go to „Functions“ and create a new component with „Start delay“.
- Enter a name at „Name“ e.g. air conditioning.
- Select your function component at „Sensor/Counter“ e.g.: hysteresis of the start delay.
- At „Interface“ enter e.g.: DO_Relais.
- At „Delay“ enter the desired start delay in seconds e.g. „10“
- Confirm with „OK“. Go to the device configuration and press „Save“.